



**Mallet Glockenspiel**

- KSK-002** for Glockenspiel, wooden head, Ø 0.3 inch
- KSK-003** for Glockenspiel, rubber head, Ø 0.3 inch
- KSK-004** for Glockenspiel, plastic head, Ø 0.3 inch



KSK-003 -4 -2

**Mallet Xylophon, Marimba**

- XRK** for Xylophon, rubber head, Ø 1 inch
- XKG** for Marimba, rubber head, Ø 1.4 inch
- XKA** for Amadinda, rubber head, Ø 2 inch



XRK

XKG

XKA

**Replacement mallet**

- KSK-002** Replacement for RT
- KL-FR** replacement for FRO
- KL-EC** replacement for EN
- KL-KU** replacement for KU
- KSK-002** Replacement for GU



**Replacement mallet Remo**

- KL-B55** replacement for BUD-55
- KL-B30** replacement for BUD-25 - BUD-40
- KL-KP** replacement for KP
- KL-SH** replacement for SHR & SHE

